



[Close Window](#)

## Jig Saws



18V Cordless Jigsaw Kit

Model 52318

- \* One-Touch™ Blade Change System for quick blade changes
- \* Kit includes Battery, Charger, Carrying Bag, Overshoe and Blades
- \* ProVantage 3-year Protection Plan

**BUY IT NOW FROM:**



## Features

- \* One-Touch™ blade change system for quick blade changes Ejects hot or broken blades with the pull of a lever.
- \* Patented Bosch blade retention Exclusive 3-way grip maintains secure blade position for precise cuts
- \* Large, die-cast aluminum foot Provides stable guidance and control. Also, comes with foot cover to protect finished surfaces.
- \* Powerful, Bosch built motor and magnesium gear housing
- \* Variable speed trigger with ambidextrous lock-off switch
- \* Ergonomic soft grip handle design with multi position grip area

Includes:

- \* (1) -- 2.4A-h Battery - BAT026
- \* (1) -- 1-Hour Charger - BC004
- \* (1) -- Carrying Bag - 2610914300
- \* (2 )-- Blades - T123X, T345XF
- \* (1) -- No Mar Overshoe - 2608000184

## Specifications

Model Number	52318
No Load SPM	0-2000

Stroke Length	1?
Length	11?"
Weight (lbs.)	6.4
Battery/Charger	1-Hour Charger
Voltage	18V
Max. Capacity in Wood	2-3/4?"
Battery Amp Hour	2.4Ah
Bevel Angle Range	45 degrees
Max. Capacity in Steel	5/16?"

## Accessories

### Featured Accessories



T-shank Jig Saw Blade Sets



T-shank Jig Saw Blades for Metal



T-shank Jig Saw Blades for Wood



T-shank Jig Saw Blades—All-purpose



T-shank Jig Saw Blades—Specialty

## Optional Attachments

### Featured Attachments

Sorry, there is no information at this time.

©2006 Bosch Tool Corporation. All rights reserved.